

## Maintaining your Icera Product

### Vitreous China Sinks

Use the tips below for regular cleaning of your Icera sink:

- Test all cleaning products in an inconspicuous area before use. Bleach, acid or alkaline detergents, and/or detergents with gritty or coarse particles should be avoided.
- Do not leave cleaning solutions on your sink surface for prolonged periods of time. Always wipe and rinse promptly after application. Refer to your cleaning product instructions for best results.
- Use a soft, non-abrasive sponge or cloth to clean your sink. Abrasive materials such as scouring pads or brushes may damage the surface.

*For warranty information, please contact Icera Customer Service department at 855-444-2372 or [service@icerausa.com](mailto:service@icerausa.com).*