



473RH, 473TB-18, 473TB-24, 473TP, 473TR


Allura® Accessories



Dimensions




473TP






473TB-18





473TB-24






Measurements		
Α	Ø 2 1/4", 57 mm	
В	3 7/8", 98 mm	
С	6", 152 mm	
D	7", 178 mm	
Е	3 1/2", 89 mm	
F	4 5/16", 110 mm	
G	6 7/8", 175 mm	
Н	3 1/2", 89 mm	
I	18", 457 mm	
J	20 1/4", 514 mm	
K	3 1/2", 89 mm	
L	24", 610 mm	
М	26 1/8", 665 mm	

Required for Installation		
Phillips head screwdriver		
Allen wrench, 3/16"		
Power Drill		

Note: Dimensions are subject to change without notice.


Installation

1) Measure and mark centerlines for mounting bracket installation using dimensions on page 2.




Notes: 473TB-18 and 473TB-24 only. Make sure both centerline marks are level.


2a) **Dry Wall Option:** Place mounting brackets into desired position. Using brackets as a guide, carefully drill 3/16" holes into wall and install anchors.




2b) **Stud Option:** Place mounting brackets into desired position. Using brackets as a guide, carefully drill 3/16" holes into wall.



 With mounting brackets in position, secure to wall using screws.



 Fully slide accessory body over mounting plate and secure with set screw.



Care and Cleaning

1) Clean finished trim area with a soft cloth using mild soap and water or a non-abrasive cleaner and then quickly rinse with water.